

Installation Guide - Downlight Series

Dear Customer,

Thank you for purchasing AZ e-lite AZSENCE LDR/LDS Series Recessed Downlights. Before beginning the installation and usage of your product, please read the safety instructions below.

A. Caution

Before beginning the downlight installation, disconnect electrical power at a main switch or circuit breaker. AZ e-lite recessed downlights' rated voltages are 220-240V. Usage of supply voltage exceeding 240V is not advised, and should be promptly switched off in such circumstances.



B. Important Safety Instructions

When installing or using downlights, please follow the basic safety precautions stated below :




1. Read all instructions before attempting any part of the installation. If you do not understand the instructions, do not attempt to install these light fixtures. Save these instructions and contact your nearest AZ e-lite dealer.
2. Downlights should be installed carefully, with maximum caution, according to the directions provided.
3. Install and mount recessed housings on a structurally sound surface.
4. Do not install any fixture assembly near high temperature conditions or combustible objects.
5. To reduce risk of fire, electric shock and potential damage to the fixtures, do not attempt to connect motors, power tools, extension cords, appliances and the like on the branch circuit serving the recessed downlights.
6. Disconnect electrical power circuit before adding to or changing the configuration of the recessed downlights.
7. In case of operation failure, please switch off the power and contact your nearest AZ e-lite dealer.

C. Installation Steps

When installing or using downlights, please follow the basic safety precautions stated below:



1. Switch off main power supply before installing the downlight. Mark the position of the downlight to be installed. The recessed downlight can be installed level with the ceilings with ceiling thickness of 9-15mm.




3. Connect the AC Cable. Make sure the conductors are connected to the correct terminals.

4. Install the Light

5. Switch on main power supply.

D. Product Line Drawing



Contact info. AZ e-lite™ (a member of Aztech Group)

31 Ubi Rd 1, #09-01, Singapore 408694 Tel: (65) 6594 2277 Fax: (65) 6749 1198 Email: sales@azelite.com.sg